


# ADSS Anchor Clamp Manual

Step 1: Make sure that the wire is within the product cable range



Step 2: Pull out the core and put the wire inside the slot.



Step 3: Adjust the position of the wire and pull the core back into the aluminum body.



Step 4: Use hand or tool to make sure that the core(each side) into the proper position and the core can't slide,the installation is complete.

